

Why Ford Protect and Your Ford Dealership Are a Perfect Match to Enhance Your Vehicle Ownership.



Drive on with best-in-class service from your Ford Dealership. Working hand-in-hand with Ford Protect, we can provide you an effortless experience to keep you on the road.

Why Ford Protect?

- Ford Protect is the only Extended Mechanical Warranty backed by Ford Motor Company
- Ford Dealers use only Genuine Ford parts and lubricants for repairs
- Ford Dealers use only Factory-trained and Certified Technicians
- Any Authorized Ford Dealer can provide repairs on your Ford
- Ford Dealers currently use the latest diagnostic equipment
- To gain the tremendous benefits Ford Protect PremiumCARE has to offer, all repairs must be performed at an authorized Ford Dealership

Drive On with Savings.



Ford Protect PremiumCARE coverage is an affordable way to limit your out-of-pocket expenses.

- Increase the resale value of your vehicle if you ever decide to sell, because this coverage is 100% transferable



For New Plans:

- Coverage begins at original warranty start date and zero kilometers. Coverage expires upon reaching your selected time or kilometers whichever occurs first.

For Used Plans:

- Coverage begins on the date of sale and the kilometers on the vehicle at the time of sale for used plans. Coverage expires upon reaching your selected time or kilometers whichever occurs first.



This brochure is intended to provide general information about PremiumCARE Extended Mechanical Warranty under the Ford Protect brand. Refer to your Plan Service and Extended Warranty Contract for pricing, plan details and terms and conditions. Ford Motor Company of Southern Africa (Manufacturing) (PTY)(LTD) FSP 48173, registration 1923/002555/07 is the Administrator of this product. The Underwriter GUARDRISK Insurance Company Limited (FSP 75, Registration 1992/001639/06).

FORD PROTECT®

PremiumCARE

— Extended Mechanical Warranty —



Drive On with Confidence.

Enjoy your vehicle worry-free, long after your New Vehicle Limited Warranty expires.


- With more than 1,000 components covered, you're protected for covered repairs down the road
- Customise a plan that's right for you with coverage terms up to 7 years or up to 200,000 km, depending on the plan and term you select.

With Ford Protect PremiumCARE Extended Warranty, you can protect your vehicle for up to 7 years or up to 200,000 km.

That's well beyond the New Vehicle Limited Warranty that comes with your vehicle. With the high cost of parts and unexpected repairs that come with owning a vehicle, it just makes sense to protect your investment with Ford Protect PremiumCARE.

Ford Protect Coverage Options

A variety of time and kilometer options are available.



Drive On for Kilometers.

There's nothing like buying a new car. It looks good. It runs great. And, of course, it has that new car smell. We want you to have that feeling with your new Ford vehicle for many kilometers to come. That's why we've created the Ford Protect PremiumCARE Extended Mechanical Warranty. So you can drive on with confidence, long after that new car smell has faded away.



Ford Protect is 100% Transferable

Your Ford Protect PremiumCARE Extended Mechanical Warranty is transferable, so if you ever decide to sell your vehicle, the new owner can take advantage of the same great coverage. This added benefit may help attract potential buyers, plus it could bring an increased resale value for you.

DRIVE ON WITH THE ONE
PLAN THAT HAS MORE THAN
1,000 COMPONENTS COVERED.

ENGINE

- All Internally Lubricated Parts
- Cylinder Block
- Cylinder Heads
- Diesel Fuel Injectors
- Diesel Injector Lines
- Diesel Injector Pump
- Diesel Lift Pump
- Engine Mounts
- Flywheel
- Flywheel Ring Gear
- Fuel Tank and Metal Lines
- Gas Fuel Injectors
- Gas Injector Lines
- Harmonic Balancer and Bolt
- Manifold (Exhaust and Bolts)
- Manifold (Intake and Bolts)
- Oil Pan
- Oil Pump
- PCM Module
- Radiator
- Radiator Fan (Clutch or Motor)
- Seals and Gaskets
- Thermostat
- Thermostat Housing
- Timing Chain Cover
- Timing Chain (Gears or Belt)
- Turbocharger/ Supercharger Unit (Factory-Installed)
- Valve Covers
- Water Pump

TRANSMISSION

- All Internally Lubricated Parts
- Release Hubs and Bearings
- Seals and Gaskets
- Torque Converter
- Transfer Case (Including All Internal Parts)
- Transmission Case
- Transmission Linkage
- Transmission Module (External)
- Transmission Mounts

ELECTRICAL

- **LED Lighting or Lamp Assemblies – Interior and Exterior (Factory-Installed)***
- Alternator
- Audiophile Sound System
- Charge and Volt Gauges
- Clock (Electric)
- Control Trac® 4WD System
- Driver's Seat Position Sensor
- Dual-Zone Electronic Auto Temp Control
- Electronic Ignition Module
- Fuel Pump
- Heated Backglass (Electrical Only – Not Glass Damage or Breakage)
- High-Intensity Discharge (HID) Headlamps*, Igniter, Ballast
- Ignition Coil and Lock
- Ignition Module (Electric)
- Ignition Switch
- Incandescent/Halogen Bulbs – Interior and Exterior*
- Intelligent 4WD Systems
- Power Mirrors (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Power Running Boards
- Radiator Fan Relay
- Rear Window Power Sunshade
- Speedometer/Odometer (Electrical and Mechanical)
- Starter Motor
- Starter Motor Solenoid
- Switches (Manually Operated Electrical)
- Temperature Gauge
- Voltage Regulator
- Wiper-Activated Headlamps
- Wiper Motors
- Wiring Harnesses (Excluding Spark Plug Wires)

*Interior/Exterior Lighting – coverage included only if Lighting Option is purchased.

BRAKES

- Anti-Lock Brake Module and Sensor
- Backing Plates
- Brake Booster (Power)
- Calipers
- Combination Valve
- ETA Pump Hose Assembly
- Metal Lines and Fittings
- Master Cylinder
- Parking Brake Linkage and Cables
- Retainers and Clips
- Self-Adjusters
- Shaft (Brake Pedal)
- Springs
- Wheel Cylinders

FRONT AND REAR SUSPENSION

- Ball Joints (Upper and Lower)
- Control Arms (Upper and Lower)
- Control Arm Shafts and Bushings
- Kingpins and Bushings
- Linkage and Bushings
- Load Leveler Suspension System
- MacPherson Struts
- Roll Stability Control
- Spindle and Spindle Support Springs
- Stabilizer Bar
- Tie Rods

REAR/FRONT-WHEEL-DRIVE AXLE

- Axle Shafts
- Bearings (Front and Rear)
- Rear: Drive Axle Housing and Front Axle Housing for 4x4 (Including All Internal Parts)
- Front: Final Drive Housing and Rear Axle Housing for AWD (Including All Internal Parts)
- Driveshaft
- Hubs Automatic Front Locking (Four-Wheel Drive)
- Locking Rings (Four-Wheel Drive)
- Seals and Gaskets
- Universal and Constant Velocity Joints

EMISSIONS

- Air Check Valve Assembly
- Air Control Valve
- Air Idle Vacuum Valve
- Air Supply Valve (Hose and Tube)
- Barometric Pressure Sensor
- DEF System (Excludes Catalyst)
- ECC Relay Assembly
- EGR Control Valve
- EGR Pressure Sensor
- EGR Regulator Asy
- EGR Valve Adapter
- Electronic Throttle Control
- EVAP Vapor Storage Canister
- Idler Air Control Valve
- Knock Sensor
- Mass Air Flow/Intake Air Temp Sensor
- Oxygen Sensor
- PCV Hose Assembly
- PCV Valve
- PCV Vapor Filter
- Reductant Urea System
- Temperature Sensor (Engine Coolant)
- Vacuum Restrictor
- VAF Sensor
- Variable Camshaft Timing (VCT) Phasers

AIR CONDITIONING & HEATING

- A/C Accumulator
- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Condenser
- Auto Temp Control
- Evaporator
- Field Coil
- Heater Blower Motor
- Heater Control Assembly
- Heater Core Assembly
- Instrument Panel Registers and Air Ducts
- Pulley

HIGH-TECH

- Adaptive Cruise Control
- Adaptive Headlamp System (Excluding Lamp Housing, Bulbs)
- Air Suspension (Selected Electronic Components)
- Anti-Theft Alarm (Factory-Installed)
- Auto Lock and Auto Unlock System
- Automatic Park Assistant
- FordLink™ System
- Ford Work Solutions Asset Security (if equipped)
- Forward Sensing Sys
- Fuel Mixer (Alternative)
- In-Dash Garmin® Voice-Activated Navigation System (Factory-Installed and Dealer)
- Instrument Cluster (Excluding Dash Pad)
- Intelligent Oil Life Monitor® System
- Keyless Entry System (Excluding Door Handles)
- Message Center
- Parallel Park Assist Sys
- Power Antenna
- Power Door Locks and Retainer Clips (Excludes Door Handles)
- Power Seat Motors
- Power Window Motors/Regulators
- Rain-Sensing Wipers
- Rear Console Refrigeration
- Reverse Camera Sys
- Reverse Sensing Sys
- SecuriCode™ Keyless Entry
- SecuriLock® Passive Anti-Theft Ignition System
- Sensor (Alcohol)
- SOS Post-Crash Alert System
- Speed Control
- Stationary Elevated Ride Control
- SYNC® MyFord Touch® (Excludes Software Upgrades)
- Trailer Brake Module
- Unique Hybrid/Electric Vehicle Components (Excluding High-Voltage Battery and Cables)

AUDIO

- Antenna, Radio (Base Assembly)
- Brackets
- Cables and Wiring
- Cellular Phone, Receiver, Handset, Speaker Assembly and Antenna (Factory-Installed)
- Compass and Therm Readout Displays
- Controls (Rear Seat)
- Radio (AM, AM/FM), Speakers, Cassette Player, Digital CD Player, Graphic Equalizer, Premium Sound Amplifier (Factory-Installed)
- Rear Entertainment System (Factory-Installed)

SAFETY

- Airbag Module Assembly
- Blind Spot Info Sys (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Collision Avoidance Sys
- Cross-Traffic System
- Diagnostic Module Assembly (Airbag)
- Door Ajar Warning Switch Assembly
- Guides, Bezels, Brackets and Supports (Safety Belts/Shoulder Straps)
- Head Restraint Retainers and Sleeves (Safety Belt)
- Key, SecuriLock® (Microchip-Encoded Key)
- Lane Depart Warning
- Lock Cylinder (Door)
- Lock Lever Asy (Door)
- Lock Lever Assembly (Tailgate)
- Lock Lever Retainers, Clips and Brackets
- Module (Passive Restraint)
- Safety Belt Buckle (Front and Rear)
- Safety Belt Motor Drive Assembly
- Safety Belt Restraint Carrier
- Safety Belt Retractors
- Safety Belt Track Asy
- Safety Belt Warning Chime Assembly
- Safety Canopy
- Sensors (Airbag)
- Shoulder Strap Track Assembly
- Wiring Asy (Airbag)

STEERING

- Column Lock (Tilt Wheel)
- Control Valve
- Cooler and Metal Lines
- Electronic Power-Assisted Steering
- Idler Arm
- Power Steering Pump/Electric Power Steering Actuator
- Pulley Assembly
- Seals and Gaskets
- Steering Column
- Steering Gear Housing, Manual and Power (Including All Internal Parts)
- Steering Shaft
- Underbody Linkages and Couplings



PremiumCARE is so comprehensive, it is easier to refer to what is not covered – here are the highlights:
Bumpers, glass, moldings, ornamentation, paint, rust, sheet metal, structural underbody framework, sideview mirrors (glass and housing), rearview mirror (glass and housing), wheel covers, studs and ornaments, service adjustments (glass and body parts), convertible top and wheels

Owner Maintenance Requirements – Service adjustments and cleaning, software upgrades, fixed (non-moving) body parts, batteries of all types and cables, belts, hoses, hose clamps, brakes (front hub, drums, shoes, linings, disc rotors, pads), manual transmission clutch disc, coolant, exhaust system (including catalytic converter), filters, fluids, lubricants, lights (bulbs, sealed beam, lenses), spark plugs, spark plug wires, squeaks and rattles, tyres, tune-ups, wheel balancing, wheel alignment, LED lights, shock absorbers and compressed natural gas/liquid propane fuel system conversion components

Components and Repairs Not Covered by PremiumCARE – Buttons, carpet, clamps, dash pad, door and window handles, knobs, trim, upholstery, CNG/LPG components, tyres, water leaks, wind noise, weatherstrips, fabric, liners, zippers and fasteners